



ИБП Eaton Powerware 9120 - UPS PW 9120 1500 VA - Руководство по подключению батарей

Постоянная ссылка на страницу: <https://eaton-power.ru/catalog/eaton-9120/>



# Read Me First

## Powerware 9120 700–1500 UPS Internal Battery Connection Instructions

Use the following procedure to ensure proper battery operation before installing the UPS:

**1** Verify that the UPS is off and unplugged.

**2** Remove the UPS front panel.

**3** Remove the protective label from the internal battery connector.

**4** Connect the internal battery connector.

**NOTE:** A small amount of arcing may occur when connecting the batteries. This is normal and does not damage the unit or present any safety concern.

**5** Reinstall the UPS front panel.

**6** Refer to the *Powerware 9120 UPS User's Guide* for UPS installation instructions.

If the UPS requires any type of transportation in the future, disconnect the UPS internal battery connector using the above steps in reverse order. If you need additional assistance, refer to the user's guide for contact information.

